



## User Manual – Chafing Dish Cover (Model series CC01, CC02, CC03)



### 1. General Information

Thank you for choosing our product. This Chafing Dish Cover (hereinafter referred to as "product" or "device") is designed to cover standard GN 1/1 chafing dishes and improve their appearance, especially in gastronomy, event, and catering settings.

**Important Note:** The Chafing Dish Cover is intended solely for aesthetic covering of chafing dishes. It does not function to heat, cook, or keep food warm. It must not come into contact with open flames or heat sources.

---

### 2. Safety Instructions

Please read this manual carefully before first use. Keep it for future reference.

**WARNING:** Observe all safety instructions of the chafing dish manufacturer. These manual complements but does not replace them.

Do not use the product near open flames, heat sources, or flammable materials. Use the product only on stable, fireproof, and dry surfaces. It is not intended for direct contact with heat sources or food. Ensure no hot surfaces are located directly beneath the product during use. Keep children and pets away from the setup area. Do not use the product to cover a chafing dish while it is in operation. Ensure the chafing dish is switched off or the fuel paste extinguished before installing or removing the cover.

---

### 3. Intended Use

This product is intended solely as an aesthetic cover for GN 1/1 chafing dishes. Any other use (e.g. as a table, cover for open flames, heat storage) is prohibited. The user is responsible for any damage resulting from improper use. Do not stack heavy or hot items on the product.

---

### 4. Preparation, Assembly and Disassembly

**General Information:** Assembly and disassembly are standardized across models. Each product comes with a separate illustrated assembly/disassembly guide. Only trained personnel should carry out assembly and disassembly. Avoid sharp edges: wear protective gloves if necessary.

**Assembly / Disassembly:** Follow the included illustrated instructions. Ensure that all corner connectors click securely into place. The Chafing Cover must be assembled/disassembled separately and may only be placed around the chafing dish when it is switched off and cooled down. Always carry the assembled cover with both hands and never upright.

Before disassembly, ensure the chafing dish is turned off and has cooled down. Release corners by simultaneously pressing and pushing the locking buttons. Store all parts dry and protected.

---

### 5. Cleaning and Care

Clean only with mild, food-safe cleaning agents and a soft cloth. Do not use abrasive, acidic, or solvent-based cleaners. Allow to dry thoroughly after cleaning. Clean only when the product is completely cooled. Store in a dry place.

---

### 6. Maintenance & Inspection

Check for visible damage before each use. Do not use if the product is warped, broken, or damaged. Original spare parts are available from the manufacturer. Technical interventions should only be carried out by authorized personnel.

---

### 7. Disclaimer

We accept no liability for: Damage resulting from disregard of this manual. Damage due to use near open flames or heat sources. Damage to third parties or property due to incorrect or improper use. Damage due to failure to follow the chafing dish manufacturer's instructions.

---

### 8. Warranty

For commercial customers, the statutory provisions of the German Commercial Code (HGB) apply. No manufacturer's warranty beyond this is provided.

We reserve the right to make technical changes as well as changes to the product, packaging, and documentation as part of our ongoing product development.

---

### 9. Disposal & Environmental Protection

Do not dispose of the product in household waste. Please take it to an appropriate recycling center for plastic and steel parts. Contact your local waste disposal authority for information.

\*Subject to change. Errors and omissions excepted.